



# DeWalt DW938 Clam Shell Replacement

How to separate the Clam Shell from the DeWalt DW938.

Written By: Christopher Chin



## INTRODUCTION

This guide will demonstrate how to separate the Clam Shell from the DeWalt DW938.

---



### TOOLS:

- [T10 Torx Screwdriver](#) (1)
  - [Sharp knife](#) (1)
-

## Step 1 — Clam Shell



- Use a torque bit screw driver to remove the T10 18.3 mm screw on the handle.
- Use a torque bit screw driver to remove 6 T10 21.5 mm screws on the handle.

⚠ Insure power source is removed from tool.

⚠ Insure blade is removed from tool.

## Step 2



- Carefully cut the safety sticker with a blade along the seam.



## Step 3



- Remove the Clam Shell from the handle unit.

---

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 12:36:08 PM.